S-Series Ultrafiltration (UF) Process Spiral Elements

PES membrane with polyester support for industrial applications



S-Series ultrafiltration process spiral elements are designed to provide extended life in a wide range of industrial fluid applications. The Polyethersulfone (PES) membrane provides excellent chemical and temperature resistance under a variety of process conditions.

Membranes Available

Membrane Type	MWCO
SB	5,000
SD	10,000
SF	20,000



Contact Information

Parker-Hannifin Corporation Bioscience & Water Filtration Division 2340 Eastman Avenue Oxnard, California, USA 93030

toll free +1 877 784 2234 phone +1 805 604 3400 fax: +1 805 604 3401 bioscience.na@parker.com

www.parker.com/industrialmembranes



Benefits

- Designed to withstand daily cleaning cycles
- Element construction developed for enhanced durability and extended life
- Elements designed to conform to FDA/CFR Title 21 standards
- Certified EU1935/2004EC & Plastics Regulation 10/2011
- Available in standard diameter or custom configurations for maximum performance and optimal cleaning
- Parker proprietary Crease Protector Technology (CPT)
- Exclusive blister-resistant technology

Applications

- Pyrogen removal
- RO Permeate polishing
- Chemical contaminant removal
- Wastewater recovery

S-Series Ultrafiltration (UF) Process Spiral Elements

Materials of Construction:

Membrane	Polyethersulfor
Support Material	Polyester
Permeate Tube	Polysulfone

- Special element construction available for high temperature/high pressure conditions/non-standard pH ranges & validation requirements
- Stainless steel permeate tube configurations available
- Polysulfone ATD & interconnectors provided

Element Dimensions

one	Maximum operating temperature*
	Typical inlet pressure**

pH range, continuous


Operating Parameters:

pH range, short-term cleaning*** Maximum chlorine concentration Other oxidizing agents**** 145°F (63°C) 100-140 psi (7-10 bar) 3 - 10 1.8 - 11.5 @ 122°F (50°C) 180 ppm @ 9-11 pH Consult factory

- * Temperature >40°C require reduced element differential
- ** Recommended cross flow rates and ΔP are dependent on various process parameters
- *** Consult factory for cleaning chemical guidelines, and cleaning water quality documents
- **** Consult with a Parker technical representative for specific limitations

Notes:

- Elements can be high temperature sanitized, consult a Parker technical representative for details
- Separate specifications are available including UF cleaning guidelines and water quality documents



Model	(D)	(/	A)	Tube ID* (C)				
	(in)	(mm)	(in)	(mm)	(in)	(mm)			
4040	4.00	101.6	40.00	1016.0	0.625	15.9			
8040	7.92	201.2	40.00	1016.0	1.125	28.6			

Lenath

Central


*Other PWT ID available upon request, consult your Parker representative for details

Element Area

	Spacer																			
	Diamond											Parallel								
Model	k	(F	D		В	(0 L		-	A M		Λ	Q		E		F		
model	` '	(.6 mm)	(28 mil)	(.7 mm)	· · · /	(0.8 mm)	` '	(1.1 mm)	` '	(1.7 mm)	` '	(2.0 mm)	(100 mil)	(2.5 mm)	· /	(1.2 mm)	` '	(1.7 mm)	` '	(2.0 mm)
	ft²	m ²	ft ²	m ²	ft²	m ²	ft ²	m ²	ft ²	m ²										
4040	84.8	7.9	78.92	7.3	74.6	6.9	60.27	5.6	43	4.0	35.9	3.3	30.1	2.8	60.27	5.6	43	4.0	35.9	3.3
8040	394.4	36.7	366.4	34.1	347	32.2	279.6	26.0	205.4	19.1	175.8	16.3	144.9	13.5	279.6	26.0	205.4	19.1	175.8	16.3

Ordering Information

Each element is identified with a product number and lot number for traceability. Example Order Configuration: SB 40 40 - BS - S



© 2019 Parker-Hannifin Corporation Bioscience & Water Filtration Division Specifications are subject to change without notification.

All Rights Reserved DS_IP_S-Series UF PE 12/13 Rev. C



ENGINEERING YOUR SUCCESS.